

COBALT FINISHING END MILLS

Multi flute Finishing end mills
 Super Cobalt – Medium and long length
 For titanium and high tensile materials
 Center Cutting

FRAISES DE FINITION EN COBALT


Fraises de Finition multi dents
 Super Cobalt – Série moyenne et longue
 Pour titan et matériaux exotiques
 Coupe au Centre

FRESAS DE ACABADO IN COBALTO

Fresas para Acabado multi labios
 Super Cobalto – Seria medio y larga
 Para titanio y materiales esoticos
 Corte al Centro

LIST 876


D	d	/	L	Z	Tool No. Uncoated	Tool No. TiCN	Tool No. TiAlN
2	2	3	6-3/4	6	876-64-3A	TC876-64-3A	TA876-64-3A
2	2	4	7-3/4	6	876-64-4A	TC876-64-4A	TA876-64-4A
2	2	6	9-3/4	6	876-64-6A	TC876-64-6A	TA876-64-6A
2	2	8	11-3/4	6	876-64-8A	TC876-64-8A	TA876-64-8A


COBALT FINISHING END MILLS

Multi flute Ball Nose Finishing end mills
 Super Cobalt – Regular length
 For titanium and high tensile materials

FRAISES DE FINITION EN COBALT

Fraises de Finition Bout
 Hémisphérique
 Super Cobalt – Série normale
 Pour titan et matériaux exotiques

FRESAS DE ACABADO IN COBALTO

Fresas para Acabado Punta Esférica
 Super Cobalto – Seria normal
 Para titanio y materiales esoticos

LIST 880


D	d	/	L	Z	Tool No. Uncoated	Tool No. TiCN	Tool No. TiAlN
1/8	3/8	3/8	2-5/16	4	880-4	TC880-4	TA880-4
3/16	3/8	1/2	2-3/8	4	880-6	TC880-6	TA880-6
1/4	3/8	5/8	2-7/16	4	880-8	TC880-8	TA880-8
5/16	3/8	3/4	2-1/2	4	880-10	TC880-10	TA880-10
3/8	3/8	3/4	2-1/2	4	880-12	TC880-12	TA880-12
1/2	1/2	1-1/4	3-1/4	4	880-16	TC880-16	TA880-16
5/8	5/8	1-5/8	3-3/4	4	880-20	TC880-20	TA880-20
3/4	3/4	1-5/8	3-7/8	4	880-24	TC880-24	TA880-24
3/4	3/4	1-5/8	3-7/8	6	880-24-A	TC880-24-A	TA880-24-A
1	1	2	4-1/2	4	880-32	TC880-32	TA880-32
1	1	2	4-1/2	6	880-32-A	TC880-32-A	TA880-32-A
1-1/4	1-1/4	2	4-1/2	6	880-40-A	TC880-40-A	TA880-40-A
1-1/2	1-1/4	2	4-1/2	4	880-48-40	TC880-48-40	TA880-48-40

